

F70 Accessories

F70 Push Synchronizer

The synchronization system for Push to Open F70 runners has been developed to ensure that wider drawers can be opened with minimum effort.

The system links the two runners, which then become a single element; applying pressure on any part of the drawer front (even at the extremities), is sufficient for the Push devices to release and consequently for the drawer to open.

The synchronization can be used with any drawer width; its functionality is at its best with drawers wider than 762 mm (30").


PRODUCT FEATURES:

- frameless or blocked out face frame applications
- smooth running action
- load capacity of the runner remains unchanged
- available on any F70 drawer length
- minimum opening (X) = 280 mm
- maximum opening (X) = 1305 mm
- bar length = 1150 cut to size



Technical information - Formula for cutting the bar to length


The assembly of the synchronizer requires a minimum 76.2 mm (3") groove in the rear of the drawer.




X = Internal width of the cabinet

Assembly instructions


Slide the carrier plates into position on the runners in the direction indicated by the arrows



Fitting the driver pins to the runners




Cut the stabilizer bar to length




Assembly instructions

Fix the bar to the plates and insert the drawer



Applying pressure on any part of the drawer front is sufficient for the drawer to open



Packaging

SYNCHRONIZER - SINGLE KIT PACKAGING

APKF7X51150



PACKAGING
Box = 20 single kits

- 1 KIT CONTAINS:
- 1 stabilizer bar
 - 2 driver pins
 - 2 carrier plates



Metal sockets

Standard metal socket





AGSK7C5B

PACKAGING
1 box = 100 pcs

- For F70 full extension runners
- Lateral self-alignment feature
- One piece stamped metal, zinc-coated
- Non-handed
- Use a minimum of 4 screws per socket

Narrow metal socket



AGSK7R5B


PACKAGING
1 box = 100 pcs

- For F70 full extension runners
- Lateral self-alignment feature
- One piece stamped metal, zinc-coated
- Non-handed
- Use a minimum of 4 screws per socket

Drilling templates for drawers

Pre-drilling for the clips reduces the possibility of splitting the wood, thus assuring the correct and level installation of the clips.

The correct and level mounting assures a smooth assembly and operation of the drawer slide.



SGD704UGXA

PACKAGING
1 box = 1 pc.


Back drilling for hook

Pre-bore for rear hook for proper alignment and depth (min. depth = 10 mm or 13/32")



Use a \varnothing 6 mm (1/4") drill bit

Angled drilling for clips, fixing on the sub-front



Use a \varnothing 2,5 mm (3/32") drill bit



Vertical drilling for clips, fixing on the bottom




Use a \varnothing 2,5 mm (3/32") drill bit

Drilling templates for drawers


Vertical fixing under the sub-front



Use a \varnothing 2,5 mm (3/32") drill bit



Tilt adjustment lever




AGLRXX3F

PACKAGING

1 box = 12 pcs right / 12 pcs left

Technical information, see page 19.

Side spacer




ASPACERFUT


For spacing out F70 runners for clearance on interior roll-outs.

PACKAGING

1 box = 100 pcs



Wood screw




V234X164

Wood screw # 6 x 16 mm (5/8")

PACKAGING

1 box = 100 pcs

Euro screw




V136X114

Euro screw # 6 x 11 mm (7/16")

PACKAGING

1 box = 100 pcs



V136X154

Euro screw # 6 x 14.5 mm (9/16")

PACKAGING

1 box = 100 pcs

Pozi driver



D2A7XCXCP

PACKAGING

1 box = 100 pcs